

Designation: D7767 - 11 (Reapproved 2018)

Standard Test Method to Measure Volatiles from Radiation Curable Acrylate Monomers, Oligomers, and Blends and Thin Coatings Made from Them¹

This standard is issued under the fixed designation D7767; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ε) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This test method describes a means to determine the percentage of processing, potential, and total volatiles from radiation curable acrylate monomers, oligomers, and blends. The results can be used to estimate the volatiles from thin radiation curable coatings that cannot otherwise be measured with the restriction that those coatings are not subjected to a pre-exposure water or solvent drying step. It also provides a means to determine the volatiles of thin radiation curable coatings in the absence of known interferences such as pigments in inks.

1.2 The values stated in SI units are to be regarded as standard. No other units of measurement are included in this standard.

1.3 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use. This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health processes and determine the applicability of regulatory limitations prior to use.

1.4 This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.

2. Referenced Documents

- 2.1 ASTM Standards:²
- D5403 Test Methods for Volatile Content of Radiation Curable Materials
- E145 Specification for Gravity-Convection and Forced-Ventilation Ovens
- E177 Practice for Use of the Terms Precision and Bias in ASTM Test Methods
- E691 Practice for Conducting an Interlaboratory Study to Determine the Precision of a Test Method
- 2.2 Other Document:³
- EPA Method 24 Determination of Volatile Matter Content, Water Content, Density, Volume Solids, and Weight Solids of Surface Coatings

3. Terminology

3.1 *Definitions:*

3.1.1 *cure*, n—conversion of a coating from its application state to its final use state measured by tests generally related to end use performance and mutually agreeable to supplier and purchaser.

3.1.2 *electron beam (EB) curing, n*—conversion of a coating from its application state to its final use state by means of a mechanism initiated by electron impingement generated by equipment designed for that purpose.

3.1.3 *pigment*, *n*—an insoluble substance added to a formulation to modify the visual appearance of a coating made from the formulation.

3.1.4 *potential volatiles, n*—the percentage loss in specimen weight upon heating at 110° C for 60 min after radiation curing.

Copyright @ ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959. United States

¹ This test method is under the jurisdiction of ASTM Committee D01 on Paint and Related Coatings, Materials, and Applications and is the direct responsibility of Subcommittee D01.21 on Chemical Analysis of Paints and Paint Materials.

Current edition approved June 1, 2018. Published June 2018. Originally approved in 2011. Last previous edition approved in 2011 as D7767 – 11. DOI: 10.1520/D7767-11R18.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

³ Available from U.S. Government Printing Office Superintendent of Documents, 732 N. Capitol St., NW, Mail Stop: SDE, Washington, DC 20401, http:// www.access.gpo.gov.

D7767 – 11 (2018)

3.1.5 *processing volatiles, n*—the percentage loss in specimen weight under process conditions that are designed to simulate actual industrial cure processing conditions.

3.1.6 *retained weight, n*—the mass of specimen remaining after exposing to the UV source, heating in an oven, or both.

3.1.7 *thin, adj*—less than 15 micrometres in thickness.

3.1.8 *total volatiles, n*—the percentage loss in specimen weight under process conditions that are designed to simulate actual industrial cure processing conditions and after heating at 110° C for 60 min.

3.1.9 *ultraviolet (UV) curing, n*—conversion of a coating from its application state to its final use state by means of a mechanism initiated by ultraviolet radiation in the range from 200 to 400 nm generated by equipment designed for that purpose.

3.1.10 UVA, n—the region of the electromagnetic spectrum comprising wavelengths falling in the range between 320 and 390 nm.

4. Summary of Test Method

4.1 A designated quantity of an acrylate-functional material (test specimen) is weighed in a container lid before and after a UV exposure step sufficient to ensure a thorough cure of the test specimen to obtain the percent solids retained. The calculated percentage weight loss is attributed to process volatiles. The test specimen and container lid are weighed again after heating for 60 min at $110 \pm 5^{\circ}$ C to obtain the percent solids retained. Any additional weight loss is attributed to potential volatiles. The total volatiles for a test specimen are the difference between the initial sample mass and the retained mass.

5. Significance and Use

5.1 This test method is an extension of Test Method D5403. While Test Method D5403 specifies that a test specimen be cured by exposure to UV or EB as prescribed by the supplier of the material, most radiation curable monomers and oligomers provided as raw materials to formulators are not designed to be used alone but rather as blends of monomers and oligomers so that there are no "supplier prescribed" exposure conditions. Test Method D5403 is not appropriate for the measurement of volatiles from thin radiation-curable coatings because supplier prescribed cure conditions include both a thickness and an exposure specification which are difficult or impossible to achieve in a test lab. Furthermore, inks form a special class of thin radiation curable coatings because they are formulated with known interferences (for example, pigments). As a result, Test Method D5403 does not provide a method for measuring volatiles from monomers and oligomers used as raw materials in the formulation of radiation curable coatings nor does it provide a method for measuring volatiles from thin radiation curable coatings such as inks.

5.2 This test method provides a means to measure the volatile content of individual acrylate monomers, oligomers, and blends commonly used to formulate radiation curable coatings such as printing inks. Such coatings comprise liquid or solid reactants that cure by polymerizing, crosslinking, or a

combination of both and are designed to be applied as thin coatings in the absence of water or solvent and to be cured by exposing to ultraviolet radiation. There is currently no direct method for measuring the volatiles from the individual materials used or thin coatings made from them.

5.3 This test method also provides a means to measure the volatiles from acrylate monomers, oligomers, and blends cured using ultraviolet radiation from which an estimate for the volatiles from a thin coating cured using ultraviolet radiation comprising these acrylate monomers, oligomers, and blends can be calculated. A common exposure step involving a specified amount of ultraviolet radiation in a specific spectral range using a common photoinitiator is called for.

5.4 This test method further provides a means to measure the volatiles from thin radiation-curable coatings such as inks in the absence of known interferences such as pigments. A common exposure step involving a specified amount of ultraviolet radiation in a specific spectral range using a common photoinitiator is called for.

5.5 If desired, volatile content can be determined as two separate components: processing volatiles and potential volatiles. Processing volatiles are a measure of volatile loss during the actual cure process. Potential (or residual) volatiles are a measure of volatile loss that might occur upon aging or under extreme storage conditions. These volatile content measurements may be useful to the producer of a material, a formulator using such materials, or to environmental interests for determining and reporting emissions.

5.6 The validity of this test method for non-acrylated radiation-curable chemistries such as methacrylates, thiol-ene, vinyl ethers, and epoxies cured using ultraviolet radiation has not been verified. Use of an electron beam to cure the acrylate monomers, oligomers, and blends or thin coatings made from them, including inks, has not been verified using this method and cannot be assumed.

6. Interferences

6.1 The degree to which the results of this procedure accurately measure the volatiles emitted is absolutely dependent upon proper cure during the test procedure. Although overcure will have little or no effect upon measured volatiles, undercure may lead to erroneously high values. To minimize variability in the cure conditions, an ultraviolet source providing a given irradiance in a specific spectral region and an exposure energy is specified as is a photoinitiator and concentration.

6.2 The presence of strong ultraviolet absorbing nonacrylate species such as pigments and ultraviolet blockers can interfere with the ability of this test procedure to accurately measure volatiles. These additives are designed to absorb, reflect, luminesce, or scatter visible or ultraviolet radiation. Such additives interfere with the proper cure of materials tested using this method and are to be avoided.

6.3 Photoinitiators are strong ultraviolet absorbers but their presence is required for proper curing.