

Wood preservatives — Method for natural preconditioning out of ground contact of treated wood specimens prior to biological laboratory test

ICS 71.100.50