



Standard Test Method for Stiffness of Fabric by the Circular Bend Procedure¹

This standard is issued under the fixed designation D4032; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This test method covers the determination of the stiffness of fabrics by the circular bend procedure.

1.2 This test method is generally applicable to all types of fabrics, including woven, knitted and nonwovens, of any fiber content.

NOTE 1—For other methods of testing for stiffness, refer to Test Methods [D1388](#).

1.3 The values stated in SI units are to be considered as standard; the values in inch-pound units are included for information only.

1.4 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Referenced Documents

2.1 *ASTM Standards:*²

[D123 Terminology Relating to Textiles](#)

[D1388 Test Method for Stiffness of Fabrics](#)

[D1776 Practice for Conditioning and Testing Textiles](#)

[D4850 Terminology Relating to Fabrics and Fabric Test Methods](#)

3. Terminology

3.1 For all terminology relating to D13.60, Fabric Test Methods, Specific, refer to Terminology [D4850](#).

3.1.1 The following terms are relevant to this standard: circular bend, stiffness.

3.2 For all other terminology related to textiles, see Terminology [D123](#).

¹ This test method is under the jurisdiction of ASTM Committee [D13](#) on Textiles and is the direct responsibility of Subcommittee [D13.60](#) on Fabric Test Methods, Specific.

Current edition approved July 1, 2012. Published August 2012. Originally approved in 1981. Last previous edition approved in 2008 as D4032 – 08. DOI: 10.1520/D4032-08R12.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

4. Summary of Test Method

4.1 A plunger forces a flat, folded swatch of fabric through an orifice in a platform. The maximum force required to push the fabric through the orifice is an indication of the fabric stiffness (resistance to bending).

5. Significance and Use

5.1 Test Method D4032 for testing stiffness of fabrics is considered satisfactory for quality control testing. It may also be used for acceptance testing of commercial shipments since the test method has been used extensively in the trade field. In cases of differences in values reported by purchaser and seller using Test Method D4032 for acceptance testing, the statistical bias, if any, between the laboratories of the purchaser and the seller should be determined with each comparison being based on the testing of specimens taken homogeneously from a lot of material of the type being evaluated. Specimens should be randomly assigned in equal numbers to each of the laboratories.

5.2 The circular bend procedure gives a force value related to fabric stiffness, simultaneously averaging stiffness in all directions. The stiffness tests in Test Methods [D1388](#) are of the single directional type.

5.3 The circular bend procedure is simple to perform and may be used for knitted, woven, or nonwoven fabrics, provided gage capacity is in keeping with fabric range tested.

6. Apparatus

6.1 *Circular Bend Stiffness Tester*,³ (Figs. 1 and 2), having the following parts:

6.1.1 *Platform*, 102 by 102 by 6 mm (4 by 4 by ¼ in.) smooth-polished chrome-plated steel plate with a 38.1-mm (1.50-in.) diameter orifice. The lap edge of the orifice should be at a 45° angle to a depth of 4.8 mm (⅜ in.) (see Fig. 3).

6.1.2 *Plunger*, 25.4-mm (1.00-in.) diameter, mounted concentric with orifice, 6.4 mm (0.25 in.) clearance on all sides. The bottom of the plunger should be set at 3 mm (⅛ in.) above the top of the orifice plate. From this position, the downward stroke length is 57 mm (2¼ in.).

³ Apparatus is commercially available.



FIG. 1 King Manual Operated Dial Model

6.1.3 *Force-Measurement Gage*, dial or digital type (see 9.3).

6.1.3.1 Dial gages with maximum reading pointer in different capacities ranging from 1 to 50 lbf, 0.5 to 25 kgf, or 5 to 200 N with 100 graduations minimum; or

6.1.3.2 Digital gage with maximum reading “hold” feature and capacity of 100 lbf, 50 kgf, or 500 N, with 1000 graduations minimum.

6.1.4 *Actuator*, manual or pneumatic.

6.2 *Specimen Marking Template*, (102 by 204 mm) 4.0 by 8.0 in.

6.3 *Stop Watch*, for checking stroke speed.

7. Sampling

7.1 *Lot Size*—For sampling purposes, a lot is defined as a single shipment of a single style of fabric. A lot may constitute all or part of a single customer order.

7.2 *Lot Sample*—As a lot sample for acceptance testing; take at random the number of rolls of fabric directed in an applicable material specification or other agreement between the purchaser and the supplier. Consider rolls of fabric to be the primary sampling units.

NOTE 2—An adequate specification or other agreement between the purchaser and the supplier requires taking into account the variability

between rolls of fabric and between specimens from a swatch from a roll of fabric to provide a sampling plan with a meaningful producer’s risk, consumer’s risk, acceptable quality level, and limiting quality level.

7.3 *Laboratory Sample*—As a laboratory sample for acceptance testing, take a full swatch 1 m (1 yd) long from the end of each roll of fabric in the lot sample, after first discarding a minimum of 1 m (1 yd) of fabric from the very outside of the rolls.

8. Number and Preparation of Test Specimens

8.1 Using the specimen marking template specified in 6.2, mark and cut five test specimens from staggered areas of each swatch in the laboratory sample. The short side of the specimen must be parallel to the machine (length) direction of the fabric. Cut no specimens closer to the selvage than one tenth of the fabric width. Lay each specimen face down and fold the specimen once to form a square 4 by 4 in. (102 by 102 mm). After folding, use the template and hand pressure to flatten the crease. Handling of specimens must be kept to a minimum and to the edges to avoid affecting stiffness properties.

NOTE 3—When otherwise agreed upon, as when specified in an applicable material specification, the purchaser and the seller may change the number of test specimens per swatch from the laboratory sample.

NOTE 4—Fabrics may also be tested face-to-face when the technical