
**Calculation method of carbon dioxide
emission intensity from iron and
steel production —**

**Part 2:
Steel plant with electric arc furnace
(EAF)**

*Méthode de calcul de l'intensité de l'émission de dioxyde de carbone
de la production de la fonte et de l'acier —*

Partie 2: Usine sidérurgique avec four à arc électrique





COPYRIGHT PROTECTED DOCUMENT

© ISO 2013

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Contents

	Page
Foreword	iv
Introduction	v
1 Scope	1
2 Terms and definitions	1
2.1 Emissions	1
2.2 Gas fuel	2
2.3 Liquid fuel	2
2.4 Solid fuel	2
2.5 Auxiliary material	3
2.6 Energy carriers	3
2.7 Ferrous containing materials	4
2.8 Alloys	4
2.9 Product and by-product	4
2.10 Others	4
3 Symbols	5
4 Principles	6
4.1 General	6
4.2 Relevance	6
4.3 Completeness	6
4.4 Consistency	6
4.5 Accuracy	6
4.6 Transparency	6
5 Definition of boundary	7
5.1 General	7
5.2 Category 1	7
5.3 Category 2	7
5.4 Category 3	8
5.5 Category 4	8
6 Calculation	8
6.1 General	8
6.2 Calculation procedure	8
Annex A (informative) Calculation of energy consumption and intensity	13
Annex B (informative) An example of template for using different emission factors or emission sources from Table 4	14
Annex C (informative) An example of CO₂ emission and intensity calculations for steel plant	16
Bibliography	19