# INTERNATIONAL STANDARD

ISO 14397-1

> Second edition 2007-09-15

## Earth-moving machinery — Loaders and backhoe loaders —

### Part 1:

Calculation of rated operating capacity and test method for verifying calculated tipping load

Engins de terrassement — Chargeuses et chargeuses-pelleteuses —

Partie 1: Calcul de la charge utile nominale et méthode d'essai pour vérifier la charge de basculement calculée



#### PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.



#### **COPYRIGHT PROTECTED DOCUMENT**

#### © ISO 2007

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

#### **Contents** Page Foreword ......iv Scope ......1 2 3 Symbols and abbreviated terms ......3 4 5 Requirements ......4 5.1 Calculation of rated operating capacity ......4 5.2 Loader configurations ......5 Procedure for calculating tipping load at maximum reach......6 5.3 Tipping load verification test.......7 6 6.1 6.2 Test equipment ......8 Test measurement of minimum tipping load ......8 6.4 Verification ......8 6.5 Test report ......8 Annex A (informative) Heavy single object (HSO) ......15