

---

**Crude petroleum and liquid or solid  
petroleum products — Determination of  
density or relative density — Capillary-  
stoppered pycnometer and graduated  
bicapillary pycnometer methods**

*Pétrole brut et produits pétroliers liquides ou solides — Détermination  
de la masse volumique ou de la densité — Méthodes du pycnomètre à  
bouchon capillaire et du pycnomètre bicapillaire gradué*



**PDF disclaimer**

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

© ISO 2004

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
Case postale 56 • CH-1211 Geneva 20  
Tel. + 41 22 749 0111  
Fax + 41 22 749 0947  
E-mail [copyright@iso.org](mailto:copyright@iso.org)  
Web [www.iso.org](http://www.iso.org)

Published in Switzerland

# Contents

Page

Foreword .....	iv
1 Scope .....	1
2 Normative references .....	1
3 Terms and definitions .....	2
4 Principle .....	2
4.1 Capillary-stoppered pycnometer .....	2
4.2 Graduated bicapillary pycnometer .....	2
5 Apparatus .....	2
6 Preparation of pycnometer .....	6
7 Calibration of pycnometer .....	6
7.1 Conditioning .....	6
7.2 Capillary-stoppered pycnometer .....	8
7.3 Graduated bicapillary pycnometer .....	8
7.4 Other reference temperatures .....	8
7.5 Recalibration .....	8
8 Procedure for capillary-stoppered pycnometers .....	9
8.1 Procedure for liquids .....	9
8.2 Procedure for solid or semi-solid samples .....	9
9 Procedure for graduated bicapillary pycnometers .....	10
10 Calculations .....	10
10.1 Symbols .....	10
10.2 Reference, calibration and test temperatures .....	11
10.3 Correction for the thermal expansion of the pycnometer .....	12
10.4 Calculation of density of a liquid .....	14
10.5 Calculation of relative density of a liquid .....	15
10.6 Calculation of density or relative density of a solid or semi-solid .....	16
11 Precision .....	16
11.1 Capillary-stoppered pycnometer method .....	16
11.2 Graduated bicapillary pycnometer method .....	17
12 Test report .....	17