



Standard Test Method for Measuring Diameter of Fine Wire by Weighing¹

This standard is issued under the fixed designation F205; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This test method covers the measurement of the average diameter of fine wire by weighing a known length; it applies particularly to sizes up to 0.13 mm used in electron devices and lamps.

1.2 The values stated in SI units are to be regarded as standard. No other units of measurement are included in this standard.

1.3 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Referenced Documents

2.1 *ASTM Standards:*²

F180 Test Method for Density of Fine Wire and Ribbon Wire for Electronic Devices

3. Apparatus

3.1 The apparatus shall consist of a suitable torsion or other direct-reading balance capable of reading to 0.002 mg or 0.1 % of the weight to be weighed (whichever is larger), with an accuracy of 0.004 mg or 0.2 % (whichever is larger). The range of the balance (or the size of the specimen) shall be such that the reading will lie within the upper half of the scale.

4. Test Specimens

4.1 Test specimens shall be selected at least 1 m from the end of a spool or sufficiently far from the end to be free from kinks or other damage resulting in lack of straightness of the cut length.

¹ This test method is under the jurisdiction of ASTM Committee F01 on Electronics and is the direct responsibility of Subcommittee F01.03 on Metallic Materials, Wire Bonding, and Flip Chip.

Current edition approved July 1, 2015. Published September 2015. Originally approved in 1945 as B205 – 45 T. Last previous edition approved in 2010 as F205 – 94(2010). DOI: 10.1520/F0205-94R15.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

4.2 The wire shall be drawn from the spool under a low even tension so that no elongation of the wire takes place.

4.3 Each test specimen shall be cut to a length of 200 ± 0.1 mm. To prevent stretching, care shall be taken so that the tension is just sufficient to eliminate the sag and curl. Any disagreement concerning the amount of tension to be used in cutting shall be resolved between the manufacturer and the purchaser.

4.4 The test specimen shall be folded upon itself several times and twisted to make a compact bundle with loop consisting of a single strand for hanging it on the balance beam. In the case of multiple specimens, all specimens shall be twisted together and hung by a loop consisting of a single strand. The specimen shall be handled as little as possible. The operator's hands shall be clean and dry.

5. Number of Specimens

5.1 Weigh a single specimen if its weight lies within the upper half of the scale of the instrument. When the weight is less than half of the scale of the instrument, weigh a sufficient number of specimens, 200 mm in length, simultaneously so that the total weight will register in the upper half of the scale, preferably as close to the limit of the balance as possible. Use the lowest range instrument compatible with the weight of the 200-mm weight specimen to reduce the number of 200-mm lengths that must be weighed together.

6. Repetition of Weighing

6.1 If the corrected weight of a single specimen lies within ± 0.5 % of either the minimum or the maximum limit specified for the wire weight, cut and weigh two more specimens of wire in a similar manner. When two or more lengths of wire have been weighed simultaneously to produce a reading in the upper half of the scale because of the small size of the wire, cut and weigh two more sets of specimens in a similar manner.

7. Calibration and Checking of the Balance

7.1 Check the balance regularly in accordance with the recommendations of the manufacturer.

7.2 If a variety of weights are to be determined, calibrate the balance at five major points on the scale and at zero by determining the weights of calibrated check weights. If any point is in error by more than 1 %, remove the balance from