
**Plastics — Determination of the
fluidity of plastics using capillary and
slit-die rheometers**

*Plastiques — Détermination de la fluidité au moyen de rhéomètres
équipés d'une filière capillaire ou plate*





COPYRIGHT PROTECTED DOCUMENT

© ISO 2021

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland

Contents

	Page
Foreword	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 General principles	4
5 Apparatus	4
5.1 Test device.....	4
5.1.1 General.....	4
5.1.2 Rheometer barrel.....	5
5.1.3 Capillary dies (method A).....	5
5.1.4 Slit dies (method B).....	9
5.1.5 Piston.....	9
5.2 Temperature control.....	9
5.3 Measurement of temperature and calibration.....	10
5.3.1 Test temperature.....	10
5.3.2 Measurement of test temperature.....	10
5.3.3 Temperature calibration.....	10
5.4 Measurement of pressure and calibration.....	10
5.4.1 Test pressure.....	10
5.4.2 Pressure drop along the length of the slit die.....	11
5.4.3 Calibration.....	11
5.5 Measurement of the volume flow rate of the sample.....	11
6 Sampling	11
7 Procedure	11
7.1 Cleaning the test device.....	11
7.2 Selection of test temperatures.....	12
7.3 Preparation of samples.....	13
7.4 Preheating.....	13
7.5 Determination of the maximum permissible test duration.....	13
7.6 Determination of test pressure at constant volume flow rate: Method 2.....	14
7.7 Determination of volume flow rate at constant test pressure: Method 1.....	14
7.8 Waiting periods during measurement.....	14
7.9 Measurement of extrudate swelling.....	14
7.9.1 General.....	14
7.9.2 Measurement at room temperature.....	15
7.9.3 Measurement at the test temperature.....	15
8 Expression of results	15
8.1 Volume flow rate.....	15
8.2 Apparent shear rate.....	16
8.2.1 General.....	16
8.2.2 Method A: Capillary dies.....	16
8.2.3 Method B: Slit dies.....	16
8.3 Apparent shear stress.....	17
8.3.1 General.....	17
8.3.2 Method A: Capillary dies.....	17
8.3.3 Method B: Slit dies.....	17
8.4 True shear stress.....	17
8.4.1 General.....	17
8.4.2 Bagley correction for capillary dies (method A).....	18
8.4.3 Bagley correction for slit dies (method B).....	21
8.4.4 Direct determination using slit dies (method B).....	22
8.5 True shear rate.....	22