

---

---

**Fine ceramics (advanced ceramics,  
advanced technical ceramics) — Test  
method for crystalline quality of  
single-crystal thin film (wafer) using  
XRD method with parallel X-ray beam**





**COPYRIGHT PROTECTED DOCUMENT**

© ISO 2020

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
CP 401 • Ch. de Blandonnet 8  
CH-1214 Vernier, Geneva  
Phone: +41 22 749 01 11  
Email: [copyright@iso.org](mailto:copyright@iso.org)  
Website: [www.iso.org](http://www.iso.org)

Published in Switzerland

# Contents

	Page
Foreword .....	iv
Introduction .....	v
<b>1 Scope .....</b>	<b>1</b>
<b>2 Normative references .....</b>	<b>1</b>
<b>3 Terms and definitions .....</b>	<b>1</b>
<b>4 Fundamentals .....</b>	<b>3</b>
<b>5 Devices and instruments .....</b>	<b>3</b>
5.1 Schematic diagrams .....	3
5.2 X-ray generator .....	4
5.3 X-ray mirror .....	5
5.4 Monochromator .....	5
5.5 Sample attachment .....	5
5.6 Goniometer .....	5
5.7 Detector .....	5
5.8 Instrument calibration .....	5
<b>6 Preparation of sample .....</b>	<b>6</b>
<b>7 Test method and procedure .....</b>	<b>6</b>
7.1 Optics alignment .....	6
7.2 Sample alignment .....	6
7.3 Adjusting the initial position of goniometer .....	7
7.3.1 Symmetric diffraction .....	7
7.3.2 Asymmetric diffraction .....	9
7.4 Microscopic position adjustment of goniometer ( $\Phi$ and $\chi$ axes) and $\omega$ scan .....	9
7.4.1 Symmetric diffraction .....	9
7.4.2 Asymmetric diffraction .....	12
7.5 Crystalline quality measurement method of single-crystal wafer .....	16
7.5.1 General .....	16
7.5.2 Selecting the flat zone position of wafer .....	16
7.5.3 Arranging the fixed size of the square .....	17
7.5.4 Measuring the FWHM value of RC .....	17
7.5.5 Interference effect by the wafer's curvature .....	17
7.5.6 Doped epitaxy film on a single-crystal thin film substrate .....	17
<b>8 Data analysis .....</b>	<b>18</b>
<b>9 Test report .....</b>	<b>18</b>
<b>Annex A (informative) Example of <math>d</math>-spacing, <math>2\theta</math>, <math>\chi</math> value (tilt angle) and relative ideal intensity of the symmetric and asymmetric diffraction on the SiC single-crystal thin film (wafer) .....</b>	<b>20</b>
<b>Annex B (informative) Determination of <math>d</math>-spacing, <math>2\theta</math>, <math>\chi</math> value (tilt angle) and relative ideal intensity for the symmetric and asymmetric diffraction on the single-crystal thin film (wafer) .....</b>	<b>22</b>
<b>Annex C (informative) Results of interlaboratory test .....</b>	<b>27</b>
<b>Bibliography .....</b>	<b>29</b>