

# Standard Practice for Alpha-Particle Spectrometry of Water<sup>1</sup>

This standard is issued under the fixed designation D3084; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon ( $\varepsilon$ ) indicates an editorial change since the last revision or reapproval.

# 1. Scope

1.1 This practice covers the processes that are required to obtain well-resolved alpha-particle spectra from water samples and discusses associated problems. This practice is generally combined with specific chemical separations, mounting techniques, and counting instrumentation, as referenced.

1.2 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.

# 2. Referenced Documents

2.1 ASTM Standards:<sup>2</sup>

- C859 Terminology Relating to Nuclear Materials
- C1163 Practice for Mounting Actinides for Alpha Spectrometry Using Neodymium Fluoride
- D1129 Terminology Relating to Water
- D3648 Practices for the Measurement of Radioactivity
- D3865 Test Method for Plutonium in Water
- D3972 Test Method for Isotopic Uranium in Water by Radiochemistry

#### 3. Terminology

3.1 For definitions of terms used in this practice, refer to Terminologies D1129 and C859. For terms not found in these terminologies, reference may be made to other published glossaries (1, 2).<sup>3</sup>

# 4. Summary of Practice

4.1 Alpha-particle spectrometry of radionuclides in water (also called alpha-particle pulse-height analysis) has been

carried out by several methods involving magnetic spectrometers, gas counters, scintillation spectrometers, nuclear emulsion plates, cloud chambers, absorption techniques, and solid-state counters. Gas counters, operating either as an ionization chamber or in the proportional region, have been widely used to identify and measure the relative amounts of different $\alpha$  -emitters. However, more recently, the solid-state counter has become the predominant system because of its excellent resolution and compactness. Knoll (3) extensively discusses the characteristics of both detector types.

4.2 Of the two gas-counting techniques, the pulsed ionization chamber is more widely used as it gives much better resolution than does the other. This is because there is no spread arising from multiplication or from imperfection of the wire such as occurs with the proportional counter.

4.3 The semiconductor detectors used for alpha-particle spectrometry are similar in principle to ionization chambers. The ionization of the gas by  $\alpha$ -particles gives rise to electronion pairs, while in a semiconductor detector, electron-hole pairs are produced. Subsequently, the liberated changes are collected by an electric field. In general, silicon detectors are used for alpha-particle spectrometry. These detectors are *n*-type base material upon which gold is evaporated or ions such as boron are implanted, making an electrical contact. A reversed bias is applied to the detector to reduce the leakage current and to create a depletion layer of free-charge carriers. This layer is thin and the leakage current is very low. Therefore, the slight interactions of photons with the detector produce no signal. The effect of any interactions of beta particles with the detector can be eliminated by appropriate electronic discrimination (gating) of signals entering the multichannel analyzer. A semiconductor detector detects all alpha particles emitted by radionuclides (approximately 2 to 10 MeV) with essentially equal efficiency, which simplifies its calibration.

4.4 Semiconductor detectors have better resolution than gas detectors because the average energy required to produce an electron-hole pair in silicon is  $3.5 \pm 0.1$  eV (0.56  $\pm 0.02$  aJ) compared with from 25 to 30 eV (4.0 to 4.8 aJ) to produce an ion pair in a gas ionization chamber. Detector resolution, defined as peak full-width at half-maximum height (FWHM), is customarily expressed in kiloelectron-volts. The FWHM increases with increasing detector area, but is typically between 15 and 60 keV. The background is normally lower for a

Copyright by ASTM Int'l (all rights reserved); Mon Jun 30 21:11:30 EDT 2014 1 Downloaded/printed by


<sup>&</sup>lt;sup>1</sup> This practice is under the jurisdiction of ASTM Committee D19 on Water and is the direct responsibility of Subcommittee D19.04 on Methods of Radiochemical Analysis.

Current edition approved June 1, 2012. Published August 2012. Originally approved in 1972. Last previous edition approved in 2005 as D3084 – 05. DOI: 10.1520/D3084-05R12.

<sup>&</sup>lt;sup>2</sup> For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

<sup>&</sup>lt;sup>3</sup> The boldface numbers in parentheses refer to the list of references at the end of this document.

Copyright © ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959. United States



semiconductor detector than for ionization chamber. Silicon detectors have four other advantages compared to ionization chambers: they are lower in cost, have superior stability, have higher permissible counting rates, and have better time resolution for coincidence measurements. However, the semiconductor detector requires sophisticated electronics because of the low charge that is generated by the incident  $\alpha$ -particle in the detector. Low-noise and high-stability, charge-sensitive preamplifiers are used prior to the detection, analog-to-digital conversion, and storage of the voltage pulse by a multichannel analyzer. The counting is nearly always performed in a vacuum chamber so that the $\alpha$ -particles will not lose energy by collisions with air molecules between the source and the detector.

4.5 A gridded pulse-ionization chamber was developed by Frisch for high-resolution alpha spectrometry. The unit consists of a standard ionization chamber fitted with a collimator between the source and the collector plate and a wire grid to shield the collector from the effects of positive ions. The resolution of a gridded pulse ionization chamber is from 35 to 100 keV for routine work. The detector parameters that affect resolution are primarily the following: statistical variations in the number of ion pairs formed at a given alpha energy, the variation in rise time of pulses, and the effects of positive ions. An advantage of gridded ionization chambers is their ability to count large-area sources with good efficiency.

4.6 There are two reasons for collimating a sample in a gridded ionization chamber. When thick-sample sources are encountered, the alpha-particles emitted at a large solid angle would show an energy degradation upon ionization of the gas. The effect leads to tailing of the alpha-particle spectrum. This problem is reduced significantly by use of the collimator. Secondly, when the nucleus following an $\alpha$  -particle emission does not decay to a ground state, the  $\gamma$ -rays that may be produced are usually highly converted, and the conversion electrons ionize the gas. The special mesh-type collimators stop the conversion electrons and collimate the source simultaneously.

4.7 A more recently developed measurement method is photon-electron-rejecting alpha liquid-scintillation spectrometry. The sample is counted in a special liquid-scintillation spectrometer that discriminates electronically against nonalpha-particle pulses. The resolution that can be achieved by this method is 250 to 300-keV FWHM. This is superior to conventional liquid-scintillation counting, but inferior to silicon detectors and gridded pulse-ionization chambers. An application of this method is given in Ref **4**.

# 5. Significance and Use

5.1 Alpha-particle spectrometry can either be used as a quantitative counting technique or as a qualitative method for informing the analyst of the purity of a given sample.

5.2 The method may be used for evaporated alpha-particle sources, but the quality of the spectra obtained will be limited by the absorbing material on the planchet and the surface finish of the planchet.

# 6. Interferences

6.1 The resolution or ability to separate alpha-particle peaks will depend on the quality of the detector, the pressure inside the counting chamber, the source-to-detector distance, the instrumentation, and the quality of the source. If peaks overlap, a better spectrometer or additional chemical separations will be required.

# 7. Apparatus

7.1 *Alpha Particle Detector*, either a silicon semiconductor or a Frisch-grid pulse-ionization chamber.

7.2 *Counting Chamber*, to house the detector, hold the source, and allow the detector system to be evacuated.

7.3 Counting Gas, for ionization chamber, typically a 90 % argon-10 % methane mixture, and associated gas-handling equipment.

7.4 *Pulse Amplification System*, possibly including a preamplifier, amplifier, postamplifier, pulse stretcher, and a high-voltage power supply, as directed by the quality and type of detector employed.


7.5 *Multichannel Pulse-Height Analyzer*, including data readout equipment. This is now often computer based.

7.6 *Vacuum Pump*, with low vapor-pressure oil and preferably with a trap to protect the detector from oil vapors.

# 8. Source Preparation

8.1 The technique employed for preparing the source should produce a low-mass, uniformly distributed deposit that is on a very smooth surface. The three techniques that are generally employed are electrodeposition, microcoprecipitation, and evaporation. The first two usually are preferred. Fig. 1 compares the alpha-particle spectrum of an electrodeposited source with that of an evaporated source.

8.1.1 Electrodeposition of  $\alpha$ -emitters can provide a sample with optimum resolution, but quantitative deposition is not necessarily achieved. Basically, the  $\alpha$ -emitter is deposited from solution on a polished stainless steel or platinum disk, which is the cathode. The anode is normally made from platinum gauze or a spiralled platinum wire, which often is rotated at a constant rate. Variants of this technique may be found in Refs **5** and **6**.



NOTE 1-Inner curve: nuclides separated on barium sulfate and then electrodeposited.

Note 2—Outer curve: carrier-free tracer solution evaporated directly. FIG. 1 Resolution Obtained on Six-Component Mixture

Copyright by ASTM Int'l (all rights reserved); Mon Jun 30 21:11:30 EDT 2014 2 Downloaded/printed by This standard is for EDUCATIONAL USE ONLY.