

INTERNATIONAL STANDARD

ISO 4343

Second edition
2000-10-15

Industrial automation systems — Numerical control of machines — NC processor output — Post processor commands

Systèmes d'automatisation industrielle — Commande numérique des machines — Informations de sortie des processeurs CN — Instructions post-processeur



Reference number
ISO 4343:2000(E)

© ISO 2000

PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

© ISO 2000

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.ch
Web www.iso.ch

Printed in Switzerland

Contents

Foreword	viii
Introduction	ix
1 Scope	1
2 Normative references	1
3 Co-ordinate system	1
3.1 Part program reference	1
3.2 Machine program reference	1
3.3 Units of measure	2
4 General structure of post processor commands	2
4.1 NC processor	2
4.2 CLDATA	2
4.3 Post processor	3
5 General language	6
5.1 General comments	6
5.2 The ADAPTV command	8
5.3 The AIR command	9
5.4 The APPLY command	10
5.5 The AUXFUN command	11
5.6 The BREAK command	12
5.7 The CALSUB command	13
5.8 The CLAMP command	14
5.9 The CLDATA command	15
5.10 The COUPLE command	16
5.11 The CUTCOM command	17
5.12 The DEFSUB command	18
5.13 The DELAY command	19
5.14 The DISPLY command	20
5.15 The END command	21
5.16 The ENDSUB command	22
5.17 The FEDRAT command	23
5.18 The GOHOME command	26