

INTERNATIONAL  
STANDARD

ISO  
20607

First edition  
2019-06

---

---

---

**Safety of machinery — Instruction handbook — General drafting principles**

*Sécurité des machines — Notice d'instructions — Principes rédactionnels généraux*



Reference number  
ISO 20607:2019(E)

© ISO 2019



**COPYRIGHT PROTECTED DOCUMENT**

© ISO 2019

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
CP 401 • Ch. de Blandonnet 8  
CH-1214 Vernier, Geneva  
Phone: +41 22 749 01 11  
Fax: +41 22 749 09 47  
Email: [copyright@iso.org](mailto:copyright@iso.org)  
Website: [www.iso.org](http://www.iso.org)

Published in Switzerland

# Contents

	Page
<b>Foreword</b>	<b>iv</b>
<b>Introduction</b>	<b>v</b>
<b>1 Scope</b>	<b>1</b>
<b>2 Normative references</b>	<b>1</b>
<b>3 Terms and definitions</b>	<b>1</b>
<b>4 Principles and general information</b>	<b>2</b>
4.1 General	2
4.2 Target group for the instruction handbook	2
4.3 Information needs	3
4.4 Comprehensible terminology and wording	3
4.5 Presentation of the instruction handbook	3
4.6 Information from component or subsystem suppliers	4
4.7 Legibility	4
4.8 Warnings, hazard and safety symbols used in the instruction handbook	4
4.9 Structuring	4
4.10 Residual risks	4
4.10.1 General	4
4.10.2 Signals and warning devices provided with the machine	4
4.11 IT security vulnerabilities	5
<b>5 Content and structure of the instruction handbook</b>	<b>5</b>
5.1 General	5
5.2 Instruction handbook content	6
5.2.1 Basic parts of an introduction handbook	6
5.2.2 Safety	7
5.2.3 Machine overview	8
5.2.4 Transportation, handling and storage	9
5.2.5 Assembly, installation and commissioning	9
5.2.6 Original equipment manufacturer settings	10
5.2.7 Operation	10
5.2.8 Product or capacity changeover	11
5.2.9 Inspection, testing and maintenance	11
5.2.10 Cleaning and sanitizing	12
5.2.11 Fault finding/troubleshooting and repair	13
5.2.12 Dismantling, disabling and scrapping	13
5.2.13 Documents and drawings	13
5.2.14 Index	14
5.2.15 Glossary	14
5.2.16 Annexes	14
<b>6 Language and formulation/style guide</b>	<b>14</b>
6.1 General	14
6.2 Language version(s)	14
6.3 Formulation guidance for instructions	14
6.4 Simple wording for instructions	15
6.5 Warnings	15
<b>7 Forms of publication</b>	<b>16</b>
<b>Annex A (informative) Correspondence between ISO 12100:2010, 6.4, and this document</b>	<b>17</b>
<b>Annex B (informative) Presentation and formatting</b>	<b>18</b>
<b>Annex C (informative) Recommendations for writing instructions</b>	<b>21</b>
<b>Bibliography</b>	<b>24</b>